

Installing the Caster Assembly



You will need a pair of work gloves and a Phillips-head screwdriver.



1

Unplug the unit from its power outlet

(not pictured)

2

Turn unit upside down. Remove bottom cover using a Phillips-head screwdriver, to remove the 4 retaining screws. Set screws aside.



3

Place caster assembly over bottom of unit, aligning the 4 screw holes on bottom cover with those on the unit.



4

Assure bottom cover is snugly in place. Use screwdriver to screw the 4 retaining screws back into place.



5

Caster assembly installed.

6

Turn unit right side up (not pictured).